THREE INPUT DOOR SENSA

COM GND
INPUT 1
INPUT 2
INPUT 3

Important

Unused sensors needs to be connected to ground

LED Indicator on sensor activation:
1 Flash = Normal operation
2 Flashes = Battery Low

DOOR SENSA INSTALLATION NOTES

1
- Mount DIN rail receiver in DB board.
- For best signal strength antenna must be mounted out of DB board housing.
- Antenna must never be cut.

2
Mount Door Sensa and Magnetic Switchs at door or windows

PATIO DOORS/WINDOWS

3 Hold the receiver LINK button until the LED starts flashing

4 Then activate one magnetic input within 25 sec

BATTERY REPLACEMENT

Pull Battery out from the top   **Insert new Battery from the side**

Remove Screws

1   **2**   **3**