



To set up the repeater:

1) Set the repeater ID number

- Press and hold the link button until the LED flashes, then release.
- Wait for the LED to flash once
- Set the repeater to an ID between 2 and 7 by pressing the link button the required amount of times.
- Press twice to set as repeater 2 and 7 times to set as repeater 7. (ID 1 should only be used after 2,3,4,5,6,7 was used)

2) Maximum repeaters in a system: 7

3) Mount repeater as high as possible, antenna to point vertically. (DO NOT cut or extend the antenna)

4) Mount repeater centrally between transmitters and receivers.

5) Never set two repeaters within a system to the same repeater ID number.

NOTE:

If the repeater is not configured with the correct ID number, it will cause problems on the network.