



Specifications

- Input supply: 230v AC 50Hz
- Splash proof enclosure
- Resistive Load: 5Kw (30AAC) Halogen bulbs, elements etc.
- Inductive: 1Kw (1.5HP) Motors, Contactors etc. see NOTE 8
- Radio frequency: 868MHz
- Distance: 30m through brick walls & floors, 100m line of sight
- Test button located on cover for immediate test function to override the check in window of 15 minutes

Linking

- 1. Hold LINK/TEST BUTTON in until LED flashes, then release.
- 2. Press the button on the transmitter....done
- 3. Repeat steps 1 & 2 for each additional transmitter button required to be linked.

To unlink:

- To unlink:

- 1. To Unlink a single transmitter button: Repeat steps 1 &2 of the linking procedure.
- 2. To clear all links in a receiver: Hold the LINK/TEST BUTTON in for approx. 10 seconds until the LED is ON solid, then release.

Notes

- A receiver can link up to a maximum of 30 di erent buttons.
- For a switched LIVE output: Add a link wire from the LIVE terminal to the COM terminal.
- For inductive loads a SNUBBER might be required, contact Ecowatt for further information.
- This product is intended for use in conjunction with the EW-GSM-CLOUD (Ecowatt Cloud Hub) for monitoring